

## **INFO:**

### **Reed valve assembly :**

**The reed valves are stapled together as they have to be installed.**

**The reed valves are labeled with top and bottom.**

**You don't have to remove the inscription, it dissolves immediately by the petrol.**

**Above is where the cylinder head is !**

**The reed valve that belongs to the top, with the corresponding support plates, is the "X version".**

**the softer reed valve, which can be recognized by the structure of the carbon, this runs at approx. 45°.**

**The structure of the lower reed valve with the corresponding support plate " A -design" the structure runs straight, i.e. in flow direction.**

**Make a mark on the top of your reed valve box, e.g. a small notch with a file**

**you will always see that the reed valve box is correctly installed.**

**The installation position is very important !!**

**Install the reed valve as they are stapled together !!**

**and always the shiny side to the outside !!!**

